

Seiko Series S23 (M796)

Depth Meter

FEATURES

- ◆ Hour, minutes, seconds, month, day, and year.
- ◆ Atmospheric pressure measurement.
- ◆ Depth meter to measure depth and water temperature.
- ◆ Dive log includes: Month, day, time, dive duration, water temperature, and maximum depth.
- ◆ 1/100 second stopwatch up to 30 hours.
- ◆ 24 hour daily alarm.
- ◆ Single time alarm.
- ◆ Depth graph and depth warning function.
- ◆ Illuminating light.

HOW TO SET TIME/ATMOSPHERIC PRESSURE (TIME MODE)

1. Time/Calendar Setting

- Press button "A" to set mode indicator to "TIME".
- Pull out button "A".
- Press button "C" to select digits.
- Press button "D" to set digits.
- Then push in button "A".

HOW TO SET DIVE MEASUREMENT (DIVE MODE)

- Measurement of depth and water temperature
- Memory of up to 5 sets of dive data.

1. Dive Measurement & Record Of Data

- A. Press button "A" to set mode indicator to DIVE.
- Press button "C" to reset and start measurement just before you submerge.
 - Press button "D" to record dive data when you have surfaced
 - Press button "A" to finish measurement.
 - Press button "C" to start a new dive.

2. Depth Warning Function

- Push button "B" to show LIMIT DEPTH SETTING display.
 - Push buttons "C" or "D" to set limit depth.
 - Push button "B" to return to DIVE MEASUREMENT display.*
- *a warning sound beeps when measurement passes set limit depth.

MAXIMUM DEPTH/DIVE DATA MEMORY (RECALL MODE)

1. Press button "A" to set mode indicator to RECALL.*

*The maximum depth in memory is displayed.

2. Press button "D" to recall dive data.*

*Maximum depth → Newest → Oldest → Maximum depth.

HOW TO USE THE STOPWATCH

- Press button "A" to set mode indicator to CHR.
- Press button "C" to Start/Stop/Restart.
- Press button "D" to Split/Split release/Reset.

1. Auto Start Function

- Press button "B" to show AUTO START TIME SETTING display.
- Press button "C" to select auto start time.

0 sec. → 5 sec. → 10 sec. → 5 min. → 1 min. → 30 sec.

- Press button "B" to return to STOPWATCH display.
 - Press button "C" to start stopwatch.*
- * Stopwatch starts automatically after set time is up.

HOW TO USE THE REGULAR ALARM (ALA. MODE)

- Press button "A" to set mode indicator to ALA.
- Press button "C" to engage/disengage alarm and hourly time signal.*

1. Alarm Time Setting

- Press button "B" to show ALARM SETTING display.
- Press button "C" or "D" to set alarm time.
- Press button "B" to return to REGULAR ALARM display.

SINGLE-TIME ALARM (TIME MODE)

- Press button "A" to set mode indicator to TIME.

1. Alarm Time Setting

- Press button "C" to show SINGLE TIME ALARM display.
 - Press button "C" or "D" to set alarm time.
 - Press button "A" to return to TIME/ATMOSPHERIC PRESSURE display.*
- *Single-time alarm is automatically engaged.

ILLUMINATING LIGHT

- Press button "D" to light up display in any mode except STOPWATCH and SINGLE-TIME ALARM modes.

